

LNB-konfiguration

1	Toneburst:	Ingen
2	DiSEqC:	Version 1.1
3	DiSEqC-parametrar:	None
4	DiSEqC-repetition:	Ingen
5	Uncommitted Switch:	Ingång 1
6	<input type="checkbox"/> Upprepning av sekvens	8 <input type="checkbox"/> Snabb DiSEqC
7	<input type="checkbox"/> Swap kommandon	

Varje DiSEqC Port konfigureras som uncommitted t.ex. port 1 ingång LNB 1 osv till port 8 LNB 8.

Every DiSEqC port configure with LNB input for ex. Diseqc 1 with LNB Input 1 etc.

LNB-konfiguration

1	Toneburst:	Ingen
2	DiSEqC:	Version 1.1
3	DiSEqC-parametrar:	None
4	DiSEqC-repetition:	Ingen
5	Uncommitted Switch:	Ingång 8
6	<input type="checkbox"/> Upprepning av sekvens	8 <input type="checkbox"/> Snabb DiSEqC
7	<input type="checkbox"/> Swap kommandon	